

SIPHON ATTACHMENT ASSEMBLY INSTRUCTIONS

1 SIPHON ATTACHMENT
3 EA. 3/8" -16 x 2" ALUMINUM TAP BOLTS
3 EA. 3/8" ALUMINUM NUTS
3 EA. 1-1/2" ALUMINUM WASHERS
3 EA. L-BRACKETS

BEFORE ASSEMBLING THE BASIN:

- 1 Attach the **SHORT SIDE** of L-bracket to the frame and the **LONG SIDE** of bracket to the siphon attachment
- 2 Attach the legs to the frame. Make sure to put the wire on after the bolt is inserted through the frame & leg, then attach the washer & nut.
- 3 After the siphon attachment is assembled, follow the assembly kit instructions to finish assembling the basin